


# Master Gauging Pallet

**Suitable for quick checking the precise alignment of Quick Changing Plates and for concentric alignment of rotary or chucks.**

## **How it works:**


After clamping the gauging pallet in a Quick Change Device - plate, the axial alignment of the Quick Change Device - plate is done by probing the jig-ground sides of the gauging pallet. For a concentric alignment the inner diameter of the gauging pallet can be used.





### M-52x52 (8010)

|               |             |
|---------------|-------------|
| Size          | 80x80x27 mm |
| Pull Stud No. | M-52x52PS   |
| Weight (kg)   | 1.1         |



### M-96x96 (8058)

|               |               |
|---------------|---------------|
| Size          | 126x126x27 mm |
| Pull Stud No. | M-96x96PS     |
| Weight (kg)   | 2.6           |

